

# 10.1 Pedestrian Walkways

## SIDEWALKS AND WALKWAYS

Sidewalks and walkways are extremely important public right-of-way components often times adjacent to, but separate from automobile traffic. In many ways, they act as the seam between private residences, stores, businesses, and the street.

There are a number of options for different settings, for both downtown and more rural and/or suburban areas. From a wide promenade to, in the case of a more rural environment, a simple asphalt or crushed stone path next to a secondary road, walkway form and topography can vary greatly. In general, sidewalks are constructed of concrete although there are some successful examples where other materials such as asphalt, crushed stone, or other slip resistant material have been used. The width of the walkways should correspond to the conditions present in any given location (i.e. level of pedestrian traffic, building setbacks, or other important natural or cultural features). FHWA (Federal Highway Administration) and the Institute of Transportation Engineers both suggest five feet as the minimum width for a sidewalk. This is considered ample room for two people to walk abreast or for two pedestrians to pass each other. Often downtown areas, near schools, transit stops, or other areas of high pedestrian activity call for much wider sidewalks.




*A well designed residential sidewalk will have a width of at least five feet. (Image from <http://www.walkinginfo.org>)*



*Sidewalk with a vegetated buffer zone. Notice the sense of enclosure created by the large canopy street trees. (Image from <http://www.walkinginfo.org>)*


*Below: Typical street with bike lanes and adjacent sidewalk.*



## SIDEWALKS AND WALKWAY GUIDELINES:

- Concrete is preferred surface, providing the longest service life and requiring the least maintenance. Permeable pavement such as porous concrete may be considered to improve water quality.
- Sidewalks should be built as flat as possible to accommodate all pedestrians; they should have a running grade of five percent or less; with a two percent maximum cross-slope.
- Concrete sidewalks should be built to minimum depth of four inches; six inches at driveways.
- Sidewalks should be a minimum of five feet wide; sidewalks serving mixed use and commercial areas shall be a minimum of 8 ft in width (12–15 feet is required in front of retail storefronts).
- Buffer zone of two to four feet in local or collector streets; five to six feet in arterial or major streets and up to eight feet in busy streets and downtown to provide space for light poles and other street furniture. See the Vegetation section later in this chapter for shade and buffer opportunities of trees and shrubs.
- Motor vehicle access points should be kept to minimum.
- If a sidewalk with buffer on both sides is not feasible due to topography and right-of-way constraints, then a sidewalk on one side is better than no facility. Each site should be examined in detail to determine placement options.

*Right: Where space and topography are limiting, this cross section may be applied.*




## GREENWAY TRAIL

A greenway is defined as a linear corridor of land that can be either natural, such as rivers and streams, or manmade, such as abandoned railroad beds and utility corridors. Most greenways contain trails. Greenway trails can be paved or unpaved, and can be designed to accommodate a variety of trail users, including bicyclists, walkers, hikers, joggers, skaters, horseback riders, and those confined to wheelchairs.

Single-tread, multi-use trails are the most common trail type in the nation. These trails vary in width and can accommodate a wide variety of users. The minimum width for two-directional trails is 10', however 12'-14' widths are preferred where heavy traffic is expected. Centerline stripes should be considered for paths that generate substantial amounts of pedestrian traffic, or along curved portions of the trail, where sight-lines are limited. Possible conflicts between user groups must be considered during the design phase, as cyclists often travel at a faster speed than other users. Radii minimums should also be considered depending on the different user groups.


While the vegetative clearing needed for these trails varies with the width of the trail. The minimum width for clearing and grubbing a 14' wide trail is 16'. Selective thinning increases sight lines and distances and enhances the safety of the trail user. This practice includes removal of underbrush and limbs to create open pockets within a forest canopy, but does not include the removal of the forest canopy itself.



*Left: Vegetation clearing guidelines*

Typical pavement design for a paved, off-road, multi-use trail should be based upon the specific loading and soil conditions for each project. Asphalt or concrete trails should be designed to withstand the loading requirements of occasional maintenance and emergency vehicles.


Right: Typical asphalt path section



Right: Typical natural surface trail section



Below: Asphalt pavement construction detail




Notes:

1. Cross slope direction varies. See layout plans for direction of slope
2. Amount of cross slope varies between 0% and 2%. See layout plans
3. Contractor is responsible for re-establishing all slopes disturbed by construction.


Concrete: In areas prone to frequent flooding, it is recommended that concrete be used because of its excellent durability. Concrete surfaces are capable of withstanding the most powerful environmental forces. They hold up well against the erosive action of water, root intrusion and subgrade deficiencies such as soft soils. Most often, concrete is used for intensive urban applications. Of all surface types, it is the strongest and has the lowest maintenance requirement, if it is properly installed.

Asphalt: Asphalt is a flexible pavement and can be installed on virtually any slope. One important concern for asphalt trails is the deterioration of trail edges. Installation of a geotextile fabric beneath a layer of aggregate base course (ABC) can help to maintain the edge of a trail. It is important to provide a 2' wide graded shoulder to prevent trail edges from crumbling.

Trail and Roadway Intersections: The images below present detailed specifications for the layout of intersections between trail corridors and roadways. Signage rules for such intersections are available in the Manual for Urban Traffic Control Devices (MUTCD).



Typical greenway trail crossing a roadway



Typical greenway trail approach to a roadway